

EH-101

Communicator/Loop Receiver



Properties

- Volume control >25dB
- Tone control
- Built-in microphone with high sensitivity
- Built-in loop receiver (possible to disconnect)
- AUX in for MP3, CD player, external microphone etc.
- Coating that reduces noise caused by touching the amplifier
- Operating time up to 300 hours
- Carrying case, neck lanyard and headset are included
- Can also be used with neck loop or hook (accessories)
- Background noise (hum) filter 500Hz

Amplify the sound from a conversation or listen to a hearing loop system.

EH-101 is a personal listener to amplify the sound from a conversation or to listen to a hearing loop system.

The built-in microphone with high sensitivity increases your chances to better hear what is said during a conversation or when you visit premises where there is a loop installed. Tone- and volume control together with a coating that reduces the sound caused by touching the amplifier makes the listening a pleasure.

A headset comes together with the amplifier. It can also be used with a neck-loop (accessory) by hearing aid wearers with hearing aid in T- or MT position.

The communicator has a built-in loop receiver and it can be used to listen to the sound in the church, at the cinema/theatre or other venues that have a hearing loop installed.

It can also be used to listen to the sound from a CD-player, MP3-player or other sound source.

EH-101 is used with 2 pieces 1,5V AA/LR06 alkaline batteries (included).

EH-101 Communicator/Loop receiver



Product overview

Technical specification

Volume control:	>25dB
Max out:	125dB SPL
Band width:	100-8000Hz \pm 1dB
Tone control:	Bass from 500Hz
AGC attack:	10mS
Distorsion:	\leq 1%
Power consumption:	10mA average, depending on out level
Battery type:	2st 1,5V AA/LR06 alkaline batteries
Battery life expectation:	>300 hours (microphone, max volume, with headset)
Size amplifier:	29x40x152mm (WxDxH)
Weight, batteries incl.:	120g



Headset

Size:	135x180mm (WxH)
Weight:	58g
Ear buds:	60mm dia



Neck loop

Length:	90cm
Weight:	35g

Part No

230850 EH-101 communicator, built-in loop receiver and headset



For additional information, please refer to User Guide/Installation Guide which can be downloaded from www.univox.eu.
If required, spare part list or other technical documents can be ordered at support@edin.se.